




Traveling Tykes (732) 942-1123

IMPORTANT! DO NOT EXPOSE TO SUNLIGHT!!!

EXPOSURE TO SUNLIGHT EVEN INDOORS WILL PERMANENTLY RUIN THE UNIT.

VR HEADSET USERS MUST BE SEATED AT ALL TIMES!!!

1. Use red magnetic cable to connect to side of unit.
2. Tap button on battery pack to turn battery pack on. Lights on battery pack and headset should go on. (The headset light should be green or orange. A white light indicates that the battery pack is incorrectly connected to the headset)



3. In order to start up the headset press on the **power button** on the top of the headset and hold down for 4 seconds.



Some units may require the **volume button** to be pressed for the videos to start playing.



- A. Select your video by moving your head and allow white dot to rest on selected video for 1.5 seconds.
- B. To return to Main Menu removed headset from your head for 3 seconds

4. **NEVER** bring oculus headsets outdoors or place under the sun **even indoors** as the headsets will get damaged.
5. **IMPT!** A white indicator light during operation shows the battery pack is disconnected.

TROUBLESHOOTING:

1. If headset says 'press volume button': Tap volume 3 or 4 times.
2. If that doesn't work: Unplug battery pack, indicator light on headset should be white, If not white then tap power button. Once white light is on, hold down power button for 10 seconds to turn unit off, then go back to step 3.

➔ **ALL HEADSETS THAT ARE RENTED OUT ARE IN PERFECT CONDITION. ANY HEADSET THAT IS DAMAGED IN ANY SHAPE OR FORM DURING THE RENTAL WILL REQUIRE A REPLACEMENT FEE OF \$400.00**